POWER BANK MANUAL

Product Introduction

Specification

Product Specifications

Cell: PB12

Capacity: 10000 mAh


Micro Input:DC5V/2A(Max)

Output1:DC5V/1A(Max)

Output2:DC5V/2.1A(Max)

Weight:227g

Dimension:69x16x137.6mm



User Manual

Thank you for purchasing our product. For optimum performance and safty, please read these instructions carefully before operating the products. Please keep this manual for future reference.

Feature

- 1.Cell type: Li-polymer battery.
- 2. Plastic housing.
- 3.Use for PC, mobile phone and various digital devices.
- 4. Multiple safety protection: over current, over charge, over voltage, short circuit protection.

How to charge your phone

Connect the mobile phone with power bank, the white light will be on, it will charge the phone automatically. When the power is finished, the white light will be flashing and be off after 30s.

How to charge the power bank

Connecting the power bank with micro port, four indicators will be flashing one by one ,and then it will show how much power left. When charging, the white light will be flashing. And it will stop flashing but still to be white when full charge.

NOTE

Please charge and restart the power bank while it is under lock status or in shortcut protection caused by incorrect operation.

Fit for:

1.samsung 2.iphone 3.mobile phone

4.MP3/MP4 5.PSP/NDS

Caution

- 1. Please completely full charge the power bank in first usage
- 2.Please make sure that use standard cable with appropriate specification or it may lead to the power bank damage
- 3. Please confirm the voltage of the electric device is 5V before charging it.
- 4.Do not drop, knock, disassemble or attempt to repair the power bank by yourself
- 5.Do not put the power bank in water or damp place
- 6.Do not expose or put the power bank near to heat sources of flammable place
- 7.Do not leave the power bank in car, because of strong sunlight and high temperature will lead to product damage
- 8. Keep the power bank away from children
- 9.Do not put any item into the power bank USB input and output ports to avoid any shortcut damage
- 10.Please make a complete charge every four month to avoid shorten the power bank life span